

Quick Start Guide

Basic Information

Icon	Operation	
	Press	Press and Hold for 3 Seconds
	Adjustable volume (0-7 levels. Level 0 is mute mode). Press to cycle through levels.	Turn LED on/off. The default status is on.
	Switch to previous or next ringtone.	Enter pairing mode.
		Clear pairing configuration, and then restore factory settings.

Use the Chime

① Plug the Chime into the Power Outlet (see part 1).

The device must be installed at a height of 2 meters or below.
Install the device as needed

② Add the Chime to the Doorbell.

1. Press and hold the  button until the LED shows a solid blue light to enter pairing mode.



The blue light stays on for 5 seconds. If it times out, press the  button again.

2. Within 5 seconds, press the call button on the doorbell. The LED will flash blue, then turn off and enter normal operation mode.
3. Press the call button on the doorbell. If the chime rings, pairing is successful.